
AR88.70-P-9040GI	Remove/install outside rearview mirror paneling	27.2.01

MODEL 163.113 /154 /174 #A as of 289565,
163.113 /154 /174 #X as of 754620,
163.128 /157 /175


1 Mirror glass
2 Outside rearview mirror paneling

Arrows Retaining lugs



P88.70-2107-11

	Remove/install		
1	Adjust mirror glass (1) toward inside.		
2	Loosen retaining lugs (arrows) in housing.	Long wedge	*115589035900
3	Remove outside rearview mirror paneling (2) toward outside.		
4	Disconnect connector from turn signal lamp.		
5	Install in the reverse order		



Long wedge